



INSTRUCTION MANUAL

LINE IMPEDANCE

STABLIZATION

NETWORK (LISN)

MODEL FCC-25/2

450 kHz – 100 MHz

INSTRUCTION MANUAL

THIS INSTRUCTION MANUAL AND ITS ASSOCIATED INFORMATION IS PROPRIETARY. UNAUTHORIZED REPRODUCTION IS FORBIDDEN.

© 1995 ELECTRO-METRICS CORP.

LINE IMPEDANCE STABILIZATION NETWORK (LISN)

ELECTRO-METRICS

MODEL FCC-25/2

SERIAL NO: N/A

ELECTRO-METRICS CORPORATION

231 Enterprise Road, Johnstown, New York 12095

Phone: (518) 762-2600

Fax: (518) 762-2812

EMAIL: info@emihq.com

WEB: <http://www.electro-metrics.com>

MANUAL REV. NO: ANS252-051995

ISSUE DATE: MAY 01 1995

WARRANTY

This Model FCC-25/2;Line Impedance Stabilization Network is warranted for a period of 12 months (USA only) from date of shipment against defective materials and workmanship. This warranty is limited to the repair of or replacement of defective parts and is void if unauthorized repair or modification is attempted. Repairs for damage due to misuse or abnormal operating conditions will be performed at the factory and will be billed at our commercial hourly rates. Our estimate will be provided before the work is started.

TABLE OF CONTENTS

SECTION	TITLE	PAGE
A-1	Appendix A: List Of Accessories	A-1
1.0	FCC-25/2 Line Impedance Stabilization Network	1
2.0	Specifications	1
3.0	Operating Instructions	2

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
1	Schematic Diagram FCC-25/2	3

APPENDIX 1
FCC-25/2 ACCESSORIES

The following accessories are standard with the FCC-25/2 POWER LINE IMPEDANCE STABILIZATION NETWORK.

- a.** Two (2) 50-ohm Termination, BNC Connector.
- b.** Six (6) Superior Plug/Pin Connectors:
 - INPUT: 3
 - OUTPUT: 3

**DESCRIPTION AND USE
LINE IMPEDANCE STABILIZATION NETWORK
ELECTRO-METRICS MODEL FCC-25/2**

1.0 Introduction

The Model FCC-25/2 Line Impedance STABILIZATION Network (LISN) is a two channel low pass filter network designed to isolate an electrically operated device from an external power source. The FCC-25/2 is used when high frequency conducted measurements are made in accordance with certain FCC standards.

The LISN is nominally designed for a 25 A (ampere) maximum load capacity which can be increased to 30 A provided that the duty cycle is reduced to 20%. The maximum line to ground voltage is set at 220 VAC and the maximum line to line voltage at 440 VAC.

2.0 Specifications

2.1 Electrical

Frequency Range:	450 kHz-100 MHz	
Network Inductance/Impedance:	50 μ H/50 Ω	
Power Line Frequency:	DC to 400 Hz 25 A Maximum Continuous Current 2 Lines	
Maximum AC Input:	Line to Line:	440 VAC
	Line to Ground:	220 VAC
Connectors:		
	Monitor Ports:	BNC
	Power Input/Output:	Superior Plug/Socket Receptacles

2.2 Mechanical

Height:	152 mm (6")
Length:	262 mm (10.3")
Width:	274 mm (10.8")
Weight:	3.6 kg (8 lbs)

3.0 Operating Instructions

Line side of the LISN (rear panel) should be connected to the power source using the three plug sockets provided (Superior Plug Sockets). Attach these plugs to the pin receptacles located on the rear panel. Ground should be made through the ground receptacle (marked GND) or a brass stud, both located on the rear panel.

WARNING

SAFETY GROUND SHOULD BE CONNECTED FIRST AND DISCONNECTED LAST ON INPUT POWER SIDE OF LISN.

NOTE: A BRASS RF GROUND STUD IS PROVIDED ON BOTH THE FRONT AND REAR PANELS FOR CONNECTING TO YOUR SHIELDED ENCLOSURE OR GROUND PLANE.

Load side of the LISN (front panel) should be connected to the load through the two socket receptacles. If a ground contact to the instrument under test is made to the power supply ground, it may be made through the ground terminal (socket receptacle or ground stud) on the front panel. No ratio isolation is provided in this line.

The BNC type coaxial connector of the line under test (monitor ports designated L1 and L2) should be connected to the interference analyzer, field intensity meter, or spectrum analyzer input. The other BNC connector must be terminated with a 50-ohm RF termination (included with LISN). It is advisable to connect the input and output terminals to their proper power lines and loads before connecting the line under test to the measurement instrumentation, otherwise it is possible to damage the input circuitry (attenuators, mixers, etc) of the test instrumentation due to power surges. Removal of a termination and connection of the BNC receptacle will not generate power surges. In addition, when power is to be disconnected, remove the power source first.

FIGURE 1
SCHEMATIC DIAGRAM FCC-25/2